



## ACRYLIC TEXTURE HI BUILD BLOCKTEX

- Description:** An elastomeric Latex based waterproofing coating, for interior/exterior surfaces, where gap filling, waterproofing and permanent flexibility is required.
- For Use On:** Concrete, concrete block walls, cementitious/stucco surfaces, Hardies Fibre Cement sheets.
- Appearance:** White, can be tinted to a wide range of pastel shades. Smooth or slightly textured as desired.
- Dry Time:** Subject to humidity. Touch dry 30 minutes, recoat 3 hours at 16°C, complete 3 coat system can take approximately 3 days to fully through dry. In moist conditions allow longer drying period.
- Cleaner/Thinner:** Water.
- Heat Resistance:** Good up to 80°C
- Durability:** Excellent
- Flammability:** Non flammable
- Application:** Best by brushing (see coating format below) or Enviropaints Texture Broom. Roller, airless spray (see coating format below).
- Coverage:** Approximately 6m<sup>2</sup> per litre, depending on substrate.
- Colour Range:** White, can be tinted to pastel/mid tone colours.
- Container Sizes:** 4 Litres, 10 Litres, 20 Litres, 200 Litres
- Surface Preparation:** New concrete, blocks, and cementitious type surfaces should be sound, dry and free of laitance, efflorescence, mould etc. New concrete should be allowed to cure for 25-28 days prior to painting. Previously painted surfaces may require waterblasting (consult your nearest Enviropaints store for advice).
- Coating Format:**
- a) 3 Coats should be applied to obtain maximum waterproofing properties by brushing or Enviropaints Texture Broom. The recommended technique is to apply each coat with a different angle of application, ie:
    - 1st Coat Up/Down Strokes
    - 2nd Coat Sideways Strokes
    - 3rd Coat Diagonal Strokes
  - b) Airless spray (not as good as texture broom or brushing)
    - Apply first coat by Texture Broom
    - Apply second coat by airless spray
    - A third fine coat may be required by airless spray



2.

**Acrylic Texture Hi Build Blocktex continued .....**

- c) Roller - Apply first and second coat by texture broom  
Apply third coat by roller.

**General Precautions:**

- a) Hi Build Blocktex will remain water sensitive until fully cured (approximately 3 days) especially in high humidity, or on damp wall surfaces. In situations where water pressure may build up behind a concrete or block wall, suitable drainage must be in place, ie drainage channels. This will minimise back pressure.
- b) All laitance/efflorescence should be removed prior to coating with Hi Build Blocktex.
- c) It is advisable to consult your nearest Enviropaints store for professional advice on waterproofing coatings, prior to starting application.
- d) Do not apply when temperature is below 12°C.
- e) Protect from freezing during storage.

**IN** the interest of personal safety Enviropaints Ltd recommend all paint products be stored securely away from children.

**ENVIROPAINTS** Ltd cares about the environment and our valued customers, if you have any questions on the product you are using from application to disposal, or require Material Safety Handling information please contact Enviropaints free phone (0800) 80 PAINT (72468).

**THE** information stated on this Data Sheet, to the best of our knowledge is true and accurate. Any recommendations or suggestions are given in good faith but without guarantee since conditions of use and application are beyond Enviropaints Ltd control. Some guarantees may apply by law.